


Instructions to Un-Install Dect6.0 Handset Manager


NOTE: These instructions are only for PC's with Microsoft® Windows® operating system.

Step 1. Go to Control Panel


- a. Click on Start button in the toolbar.
- b. With your mouse select Settings – Control Panel




Step 2. Double Click on “Add or Remove Programs” in the Control Panel.




Step 3. Find “DECT6.0 HandsetManager” in the programs list and click with the mouse to select.



Step 4. Click “Remove” on the “DECT6.0 HandsetManager” listing.



Step 5. Click “Yes” on the display prompt to uninstall the “DECT6.0 HandsetManger”.



Step 6. The program will be uninstalled from your computer.